



12" Installation Instructions

1. Check to see that all parts are included in your package before beginning installation
2. Your kit should contain the following parts:
 - 2 – 12" lengths of T-Track
 - 2 – 10" x 3/4" x 3/16" Aluminum Flat Bar with 2 threaded mounting holes
 - 4 – 1/4-20 x 1" Stainless Steel Flat Head Phillips mounting screws
 - 2 – Chrome Plated Eyebolts
 - 2 – Black Plastic Flat Washers
 - 2 – 3/8" Square Head Studs
3. Determine where you want to install the T-Tracks on your truck bed
4. Measure and layout the position for the top hole of the T-Track
5. Measure down and mark the second hole 9" from the first mounting hole
6. Drill a 5/16" hole at each mark.
7. Place one of the 1/4-20 flat head screws through one hole of the T-Track and insert the screw through the top hole that you just drilled in the truck bed.
8. Place the aluminum flat bar between the cab of the truck and the truck bed and screw the T-Track into one of the holes in the aluminum flat bar. Do not tighten this screw yet.
9. Once you have started the screw into the flat bar, release the flat bar and let it fall so that it hangs down between the back of the cab and the truck bed.
10. The bottom hole of the flat bar should now line up with the bottom hole of the T-Track.
11. Insert the other 1/4-20 flat head screw into the bottom hole of the T-Track and thread it into the bottom hole of the Flat Bar
12. Tighten both screws and repeat the procedure for the next section of T-Tracks.