



2'' Installation Instructions

1. Position the first T Track section with holes centered on top of truck bed lip.
2. Mark the center of the T Track mounting holes on the bed lip.
3. Center punch and drill pilot holes with 1/8'' or smaller drill.
4. If the holes can be accessed under the truck bed lip, drill the pilot holes out with a 1/4'' bit.
5. To access the holes closest to the tailgate, it may be necessary to remove the rear taillight.
6. If holes cannot be accessed under the truck bed lip, use a 13/64'' or #7 drill bit for use with self-tapping screws supplied.
7. Lay a bead of silicone sealant down each side of the drilled holes as well as a bead around each drilled hole.
8. Mount T Track on bed lip and fasten down with supplied hardware.
9. For those holes that were not accessible under the truck bed lip, screw the 1/4''-20 self tapping screws right into truck bed lip.
10. Remove self-tapping screw and replace with stainless steel screw.
11. Re-install truck taillight.
12. Lay second T Track section with the factory cut ends together.
13. If necessary, cut back T Track to desired length for truck bed with a chop saw or hacksaw.
14. Be careful to cut the end of the T Track that will be immediately behind truck cab when mounted.
15. Use the wooden jig supplied to align the two sections of track by inserting the tapered end into the track slot.
16. Make sure that the second section of track is butted right up against the first section with no gap between them.
17. Follow the same procedure for fastening the second section to the truck as the first section.